



SADOWSKY GUITARS LTD.

20 JAY STREET #5C
BROOKLYN, NEW YORK 11201

TELEPHONE (718) 422-1123
FAX (718) 422-1120

SADOWSKY GUITAR CONTROLS



MINI-TOGGLE SWITCH

Up: Bypass (*Passive Mode*)
Middle: Midrange Boost (*active mode*)
Down: Midrange Boost + Gain

The midrange pot is a boost control. Flat response in the active mode is with the midrange pot rolled off to “0” (fully counter-clockwise).

The amount of gain boost is adjustable on a small trimpot. On guitars with pickguards, the trimpot is accessible through a hole on the tremolo backplate. On guitars with rear control cavities, the trimpot is mounted directly on the circuit board located in the control cavity. A low amount of gain boost (our preset) is perfect for “cutting through” on solos or use maximum gain to overdrive the input stage of your tube amp for a nice “crunch” distortion.

We encourage you to try the preamp whenever you go through any pedals or effects. You will be surprised at how much better your pedals sound with an active output from your guitar.

The circuit in this guitar is of professional quality and designed for the least amount of noise. The premium quality chip in the guitar has a battery life rated at 1,000 hours. Depending on use, this can mean battery life of over one year. Please note that the battery is being drained whenever the guitar is plugged in, regardless of the mini-switch setting.